












Montage Sport Scheibe - Sport screen instructions

6531308




NR	TEILE / PARTS	MENGE	BESCHREIBUNG	DESCRIPTION
1		x1	Ermamax Sport Scheibe	Ermamax Sport screen
2		x1	Halter rechts	Right fixing lug
3		x1	Halter links	Left fixing lug
4		x2	<i>originale Schraube M6 x 14 BHC</i>	<i>M6 x 14 Original BHC screw</i>
5		x2	<i>originale Schraube M6 x 10 BHC</i>	<i>M6 x 10 Original BHC screw</i>
6		x2	Schraube M6 x 20 FHC schwarz	M6 x 20 Black FHC screw
7		x4	Schraube M5 x 20 BHC schwarz	M5 x 20 Black BHC screw
8		x4	Gummieinsatz mit M5 Gewinde	Ø5 Wide rubber insert
9		x4	Kunststoffunterlegscheibe Ø5	Ø5 Nylon washer
10		x2	Metalldistanz Ø8, Höhe 10 mm	Metal spacer Ø8, height 10 mm


1 Demontage - Disassembly



Montage - Assembly 2



3 Montage Assembly



Montage - Assembly 4

